BookletChart[™]

Grand Marais to Big Bay PointNOAA Chart 14963



A reduced-scale NOAA nautical chart for small boaters When possible, use the full-size NOAA chart for navigation.



- Complete, reduced-scale nautical chart
- Print at home for free
- Convenient size
- Up-to-date with Notices to Mariners
- Compiled by NOAA's Office of Coast Survey, the nation's chartmaker

14963 LARVE GERBERGER			Approx	imate Page Inc	SOURCE	S IN FEET	
	4 2000	5 L A K	6	U- P- E Ř	8	9	,
	10	111	12	13	14	15	
	Section of the sectio				CRA CRA	Total State of the Control of the Co	
13	STATE OF THE PROPERTY OF THE P	SOUNDINGS IN FEET	ena de la companya de	To an and the second se	The state of the s	Grand Marie to Big Bay Print) 14963 LIMAN CHARPEISTED	

Published by the National Oceanic and Atmospheric Administration National Ocean Service Office of Coast Survey

<u>www.NauticalCharts.NOAA.gov</u> 888-990-NOAA

What are Nautical Charts?

Nautical charts are a fundamental tool of marine navigation. They show water depths, obstructions, buoys, other aids to navigation, and much more. The information is shown in a way that promotes safe and efficient navigation. Chart carriage is mandatory on the commercial ships that carry America's commerce. They are also used on every Navy and Coast Guard ship, fishing and passenger vessels, and are widely carried by recreational boaters.

What is a BookletChart[™]?

This BookletChart is made to help recreational boaters locate themselves on the water. It has been reduced in scale for convenience, but otherwise contains all the information of the full-scale nautical chart. The bar scales have also been reduced, and are accurate when used to measure distances in this BookletChart. See the Note at the bottom of page 5 for the reduction in scale applied to this chart.


Whenever possible, use the official, full scale NOAA nautical chart for navigation. Nautical chart sales agents are listed on the Internet at http://www.NauticalCharts.NOAA.gov.

This BookletChart does NOT fulfill chart carriage requirements for regulated commercial vessels under Titles 33 and 44 of the Code of Federal Regulations.

Notice to Mariners Correction Status

This BookletChart has been updated for chart corrections published in the U.S. Coast Guard Local Notice to Mariners, the National Geospatial Intelligence Agency Weekly Notice to Mariners, and, where applicable, the Canadian Coast Guard Notice to Mariners. Additional chart corrections have been made by NOAA in advance of their publication in a Notice to Mariners. The last Notices to Mariners applied to this chart are listed in the Note at the bottom of page 7. Coast Pilot excerpts are not being corrected.

For latest Coast Pilot excerpt visit the Office of Coast Survey website at http://www.nauticalcharts.noaa.gov/nsd/searchbychart.php?chart=149



(Selected Excerpts from Coast Pilot)
Grand Marais, MI is a village and small-craft harbor in West Bay,29 miles west of
Little Lake Harbor. It is an important
harbor of refuge, being the only harbor of
any kind along the dangerous 65-mile
stretch of shore between Little Lake and
Grand Island. The bay is separated from
Lake Superior at the west end by a low
sand ridge and at the E end by a shallow
sandspit. The natural entrance to the bay,
across the spit, has been closed by a pile

dike. The dike is reinforced with riprap, but in 1981, it was in ruins and was not visible above the water. Numerous submerged piles at the dike are a hazard to any craft.

Prominent features.—Prominent are a red brick school and chimney in the village and a white building on the west side of the harbor entrance. **Grand Marais Harbor of Refuge Outer Light** (46°41'02"N., 85°58'18"W.), 40 feet above the water, is shown from a skeleton tower, upper part enclosed, on the outer end of the west pier; a seasonal sound signal is at the light.

Channels.—A dredged entrance channel leads between parallel piers across the sandspit which separates Lake Superior and West Bay. The outer and inner ends of the W pier and the outer end of the east pier are marked by lights. In 2006, the controlling depth in the channel was 12.2 feet (14.7 feet at midchannel).

Anchorage.—West Bay has good anchorage in depths of 18 to 40 feet, sand bottom. Sand moving in through breaks in the dike has caused shoaling in the E end of the harbor, so anchorage in the west end is advised.

Grand Marais Coast Guard Station, operated on weekends during the boating season, is on the west side of the entrance channel. **Small-craft facilities.**—A public dock developed by the Michigan State Waterways Commission at the west end of the harbor provides transient berths, gasoline, diesel fuel, water, electricity, sewage pump-out facilities, and a launching ramp. Arrangements can be made for minor repairs.

From Grand Marais, the shore extends west-southwest for 7 miles, thence northwest for 1.7 miles to Au Sable Point. **Grand Sable**, a steep bluff with elevations of 400 feet above the lake, extends from 1 mile west of Grand Marais to within 1 mile of Au Sable Point. Shoals extend 0.2 to 0.4 mile offshore in this stretch.

Au Sable Light (46°40.3'N., 86°08.4'W.), 100 feet above the water, is shown from a white conical tower, red dwelling attached, on **Au Sable Point**.

Local magnetic disturbance.—A large area of magnetic disturbance has been observed about 40 miles northwest of Au Sable Point.

A shoal with a least depth of 6 feet extends 0.9 mile northwest from Au Sable Point.

Pictured Rocks National Lakeshore occupies the entire shore from 1.5 miles west of Grand Marais W to Au Sable Point, thence southwest for 28 miles to within 2.5 miles of Munising.

From Au Sable Point, the shore extends southwest for 17.5 miles to **Grand Portal Point.** The shore for most of this reach is bluff with high points up to 100 feet above the lake close to shore. About 4 miles northeast of Grand Portal Point, the shore changes to sheer exposed cliffs over 100 feet high. Except for 23- and 24-foot shoals about 0.5 mile offshore 3 and 4 miles northeast of Grand Portal Point, respectively, no outlying obstructions are along this stretch.

From Grand Portal Point, the shore trends southwest for 9.7 miles to **Sand Point.** The cliffs of Pictured Rocks extend along the first 8 miles of this stretch. **Sail Rock** and **Miners Castle Point,** 1 and 6 miles southwest of Grand Portal Point, respectively, are prominent. S of Pictured Rocks, a high wooded bluff continues close to shore past Sand Point. Shoals extend about 0.3 mile offshore in this stretch. About 2.2 miles southwest of Miners Castle Point, a shoal with a least depth of ½ foot makes out from shore and extends southwest to a point 0.3 mile northwest of Sand Point. The shoal is marked by a lighted bell buoy.

U.S. Coast Guard Rescue Coordination Center 24 hour Regional Contact for Emergencies

RCC Cleveland Commander

9th CG District (216) 902-6117

Cleveland, OH

2



CAUTION

SUBMARINE PIPELINES AND CABLES Charted submarine pipelines and submarinables and submarine pipeline and cable reas are shown as:

Cable Area

Additional uncharted submarine pipeline and submarine cables may exist within the cable of this chart. Not all submarine pipelin and submarine cables are required to be buried, and those that were originally buried may have become exposed. Mariners should use extreme caution when operating vessels if depths of water comparable to their draft in areas where pipelines and cables may exis-

nlighted buoys.

Temporary changes or defects in aids to navigation are not indicated on this chart. See Notice to Mariners.

During some winter months or when en-dangered by ice, certain aids to navigation are replaced by other types or removed. For details see U.S. Coast Guard Light List.

RADAR REFLECTORS

Radar reflectors have been placed on many floating aids to navigation. Individual radar reflector identification on these aids has been omitted from this chart.

CAUTION

Only marine radiobeacons have been calibrated for surface use. Limitations on the use of brated for sunder use, Limitations on the use certain other radio signals as aids to marine navigation can be found in the U.S. Coast Guard Light Lists and Defense Mapping Agency Publication 117.

Radio direction-finder bearings to commer-

cial broadcasting stations are subject to error and should be used with caution. Station positions are shown thus:

⊙(Accurate location) o(Approximate location)

CAUTION

Improved channels shown by broken lines are subject to shoaling, particularly at the edges.

NOAA VHF-FM WEATHER BROADCASTS

The National Weather Service stations listed below provide continuous marine weather broadcasts. The range of reception is vari-able, but for most stations is usually 20 to 40 miles from the antenna site.

Marquette, Mi. KIG-66 162.55 MHz (Chan.WX-1) Houghton, Mi. WXK-73 162.40 MHz (Chan.WX-2)

Low Water Datum, which is the plane of reference for the levels shown on the above hydrograph, is also the plane of reference for the charled debths. If the lake level is above or below Low Water Datum, the existing depths are correspondingly greater or lesser than the charled depths

HORIZONTAL DATUM

The horizontal reference datum of this chart is North American Datum of 1983 (NAD 83), which for charting purposes is considered equivalent to the World Geodetic System 1984 (WGS 84). Geographic positions referred to the North American Datum of 1902 must be corrected an average of 0.527" southward and 0.776" westward to agree with this chart.

SOURCE DIAGRAM

The outlined areas represent the limits of the most recent hydrographic survey information that has been evaluated for charting. Charter hydrography may originate from these and prior surveys.

The prudent mariner will not rely solely on any single aid to navigation, particularly on floating aids. See U.S. Coast Guardight List and U.S. Coast Pilot 6 for details.

POLLUTION REPORTS

Report all spills of oil and hazardous substances to the National Response Center via 800-424-8802 (tall free), or to the nearest U.S. Coast Guard facility if telephone communication is impossible (33 CFR 153).

Table of Selected Chart Notes

avigation regulations are published in Chapter 2, U.S. Coast Pilo 6. Additions or revisions to Chapter 2 are published in the Notice to Mariners. Information concerning the regulations may be obtained a the Office of the Commander, 9th Coast Guard District in Cleveland Ohio, or at the Office of the District Engineer, Corps of Engineers in Detroit, Michigan.

Due to periodic high water conditions in the Great Lakes, some features charted as visible at Low Water Datum may be submerged, particularly in the near shore areas. Mariners should proceed with

Sailing courses and limits indicated in magenta are recommended by the Lake Carriers Association and the Canadian Shipowners Association.



CAUTION

POTABLE WATER INTAKE (PWI)

Vessels operating in fresh water lakes or rivers shall not discharge sewage, or ballast, or bilge water within such areas adjacent to domestic water intakes as are designated by the Commissioner of Food and Drugs (21 CFR 1250.93). Consult U.S. Coast Pilot 6 for important supplemental information.

SYMBOLS AND ABBREVIATIONS. For complete list of symbols and abbreviations see Chart No. 1.


AIDS TO NAVIGATION. Consult U.S. Coast Guard Light List for supplemental information concerning aids to navigation.

SAILING DIRECTIONS. Bearings of sailing courses are true and distances given thereon are in statute miles between points of departure.


PLANE OF REFERENCE OF THIS CHART (Low Water Datum) Referred to mean water level at Rimouski, Quebec, International Great Lakes Datum(1985).


BRIDGE AND OVERHEAD CABLE CLEARANCES. When the water surface is above Low Water Datum, bridge and overhead clearances are reduced correspondingly. For clearances see U.S. Coast Pilot 6.


AUTHORITIES. Hydrography and topography by the National Ocean Service, Coast Survey with additional data from the Corps of Engineers, Geological Survey, and U.S. Coast Guard.




















Note: Chart grid lines are aligned with true north.


Printed at reduced scale. YARROS See Note on page 5.


STATUTE MILES STATUTE MILES STATUTE MILES STATUTE MILES SEE Note on page 5.


SOUNDINGS IN FEET


Nautical Chart Catalog No. 4, Panels B & C





























Note: Chart grid lines are aligned with true north. Printed at reduced scale. YARDS See Note on page 5.

See Note on page 5.


Statute MILES


Statute MILES

See Note on page 5.


STATUTE MILES

To a series of the s





Note: Chart grid lines are aligned with true north. The state of the s





VHF Marine Radio channels for use on the waterways:

Channel 6 – Inter-ship safety communications.

Channel 9 – Communications between boats and ship-to-coast.

Channel 13 – Navigation purposes at bridges, locks, and harbors.

Channel 16 – Emergency, distress and safety calls to Coast Guard and others, and to initiate calls to other

vessels. Contact the other vessel, agree to another channel, and then switch.

Channel 22A – Calls between the Coast Guard and the public. Severe weather warnings, hazards to navigation and safety warnings are broadcast here. Channels 68, 69, 71, 72 and 78A – Recreational boat channels.

Getting and Giving Help — Signal other boaters using visual distress signals (flares, orange flag, lights, arm signals); whistles; horns; and on your VHF radio. You are required by law to help boaters in trouble. Respond to distress signals, but do not endanger yourself.

Distress Call Procedures

- Make sure radio is on.
- Select Channel 16.
- Press/Hold the transmit button.
- Clearly say: "MAYDAY, MAYDAY, MAYDAY."
- Also give: Vessel Name and/or Description; Position and/or Location; Nature of

Emergency; Number of People on Board.

- · Release transmit button.
- Wait for 10 seconds If no response Repeat MAYDAY call.

HAVE ALL PERSONS PUT ON LIFE JACKETS!



NOAA Weather Radio All Hazards (NWR) is a nationwide network of radio stations broadcasting continuous weather information directly from the nearest National Weather Service office. NWR broadcasts official Weather Service warnings, watches, forecasts and other hazard information 24 hours a day, 7 days a week.

http://www.nws.noaa.gov/nwr/

Quick References

Nautical chart related products and information — http://www.nauticalcharts.noaa.gov

Online chart viewer — http://www.nauticalcharts.noaa.gov/mcd/NOAAChartViewer.html

Report a chart discrepancy — http://ocsdata.ncd.noaa.gov/idrs/discrepancy.aspx

Chart and chart related inquiries and comments — http://ocsdata.ncd.noaa.gov/idrs/inquiry.aspx?frompage=ContactUs

Chart updates (LNM and NM corrections) — http://www.nauticalcharts.noaa.gov/mcd/updates/LNM_NM.html

Coast Pilot online — http://www.nauticalcharts.noaa.gov/nsd/cpdownload.htm

Tides and Currents — http://tidesandcurrents.noaa.gov

Marine Forecasts — http://www.nws.noaa.gov/om/marine/home.htm

National Data Buoy Center — http://www.ndbc.noaa.gov/

NowCoast web portal for coastal conditions — http://www.nowcoast.noaa.gov/

National Weather Service — http://www.weather.gov/

National Hurrican Center — http://www.nhc.noaa.gov/

Pacific Tsunami Warning Center — http://ptwc.weather.gov/

Contact Us — http://www.nauticalcharts.noaa.gov/staff/contact.htm



For the latest news from Coast Survey, follow @nauticalcharts



This Booklet chart has been designed for duplex printing (printed on front and back of one sheet). If a duplex option is not available on your printer, you may print each sheet and arrange them back-to-back to allow for the proper layout when viewing.

